



Professional, high-resolution counting scale with 100 item memories and second balance interface, counting resolution up to 75,000 points

Features

- **Memory (PLU)** for 99 items with additional text, reference weight and tare weight, e.g. of a container
- **Precise counting:** The automatic reference weight optimisation of reference weight gradually improves the average piece weight value
- **Programmable using numerical key pad:**
 - required reference quantity
 - known reference weight
- **Weighing with tolerance range (check-weighing):** a visual and audible signal helps with portioning, dispensing or grading
- **Fill-to-target function:** Programmable target quantity or target weight. A signal will be displayed when the target value is reached
- **PRE-TARE function** for manual subtraction of a known container weight, useful for checking fill-levels

- **Second balance interface** to construct a high-resolution counting system, standard, e.g. with weighing bridges KERN KFP-V20

Technical data

- Large backlit LCD displays, digit height 20 mm
- Weighing plate dimensions W×D×H
 - A Ø 80 mm
 - B W×D 300×225 mm, see larger picture
 - C W×D 320×350 mm
- Overall dimensions W×D×H
 - A 320×350×180 mm (incl. draught shield)
 - B 320×350×125 mm
 - C 320×350×125 mm
- Permissible ambient temperature 0 °C/40 °C

Accessories

- **Protective working cover**, standard for models with weighing plate size A, B, can be re-ordered, scope of delivery: 5 items, KERN CFS-A02S05
- **Rechargeable battery pack internal**, operating time up to 70 h without backlight, charging time approx. 14 h, KERN GAB-A04
- **Signal lamp** for visual support of weighing with tolerance range, KERN CFS-A03
- **Y-cable** for parallel connection of two terminal devices to the RS-232 interface on the scale, e.g. signal lamp or barcode reader and printer, KERN CFS-A04
- **WLAN interface** for wireless connection of the balance to networks and WLAN capable devices, such as tablets, laptops or smartphones, KERN CFS-A05
- Further details, plenty of further accessories and suitable printers see *Accessories*

STANDARD



OPTION



Model	Weighing range [Max] kg	Readout [d] g	Smallest part weight [counting] g/piece	Counting resolution Points	Net weight approx. kg	Weighing plate	Options	
							DAkkS Calibr. Certificate	
							DKD KERN	
KERN								
CFS 300-3	0,3	0,001	0,005	60.000	2,6	A	963-127	
CFS 3K-5	3	0,01	0,05	60.000	3,4	B	963-127	
CFS 6K0.1	6	0,1	0,1	60.000	3,4	B	963-128	
CFS 15K0.2	15	0,2	0,2	75.000	3,4	B	963-128	
CFS 30K0.5	30	0,5	0,5	60.000	3,4	B	963-128	
CFS 50K-3	50	1	1	50.000	4,4	C	963-128	

KERN Pictograms:



Internal adjusting: Quick setting up of the balance's accuracy with internal adjusting weight (motordriven).



Piece counting: Reference quantities selectable. Display can be switched from piece to weight.



Rechargeable battery pack: Rechargeable set.



Adjusting program CAL: For quick setting up of the balance's accuracy. External adjusting weight required.



Recipe level A: Separate memory for the weight of the tare container and the recipe ingredients (net total).



Universal mains adapter: with universal input and optional input socket adapters for
A) EU, GB
B) EU, GB, CH, USA
C) EU, GB, CH, USA, AUS



Memory: Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



Recipe level B: Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display.



Mains adapter: 230V/50Hz in standard version for EU. On request GB, USA or AUS version available.



Alibi memory: Electronic archiving of weighing results, complying with the 2014/31/EU standard.



Recipe level C: Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display, multiplier function, adjustment of recipe when dosages are exceeded or barcode recognition.



Power supply: Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request.



Data interface RS-232: To connect the balance to a printer, PC or network.



Weighing principle: Strain gauge
Electrical resistor on an elastic deforming body.



RS-485 data interface: To connect the balance to a printer, PC or other peripherals. High tolerance against electromagnetic disturbance.



Totalising level A: The weights of similar items can be added together and the total can be printed out.



Weighing principle: Tuning fork
A resonating body is electromagnetically excited, causing it to oscillate.



USB data interface: To connect the balance to a printer, PC or other peripherals.



Percentage determination: Determining the deviation in % from the target value (100 %).



Weighing principle: Electromagnetic force compensation Coil inside a permanent magnet. For the most accurate weighings.



Bluetooth* data interface: To transfer data from the balance to a printer, PC or other peripherals.



Weighing units: Can be switched to e.g. non-metric units at the touch of a key. See balance model. Please refer to KERN's website for more details.



Weighing principle: Single cell technology
Advanced version of the force compensation principle with the highest level of precision.



WLAN data interface: To transfer data from the balance to a printer, PC or other peripherals.



Weighing with tolerance range: Upper and lower limiting values can be programmed individually for e.g. dosing, sorting and portioning.



Verification possible:
The time required for verification is specified in the pictogram.



Control outputs (optocoupler, digital I/O): To connect relays, signal lamps, valves, etc.



Hold function: (Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value.



DAKkS calibration possible (DKD): The time required for DAKkS calibration is shown in days in the pictogram.



Interface for second balance: For direct connection of a second balance.



Protection against dust and water splashes IPxx: The type of protection is shown in the pictogram.



Package shipment: The time required for internal shipping preparations is shown in days in the pictogram.



Network interface: For connecting the scale to an Ethernet network. With KERN products you can use a universal RS-232/LAN converter.



ATEX explosion protection: Suitable for use in hazardous industrial environments, in which there is explosion danger. The ATEX marking is specified for each device.



Pallet shipment: The time required for internal shipping preparations is shown in days in the pictogram.



Wireless data transfer: between the weighing unit and the evaluation unit using an integrated radio module.



Stainless steel: The balance is protected against corrosion.



Warranty: The warranty period is shown in the pictogram.



GLP/ISO log: The balance displays the weight, date and time, regardless of a printer connection.



Suspended weighing: Load support with hook on the underside of the balance.



GLP/ISO log: With weight, date and time. Only with KERN printers.



Battery operation: Ready for battery operation. The battery type is specified for each device.

KERN – Precision is our business

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAKkS calibration certificate the best pre-requisite for proper balance calibration.

The KERN DAKkS calibration laboratory today is one of the most modern and best-equipped DAKkS calibration laboratories for balances, test weights and force-measurement in Europe.

Thanks to the high level of automation, we can carry out DAKkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

Range of services:

- DAKkS calibration of balances with a maximum load of up to 50 t
- DAKkS calibration of weights in the range of 1 mg - 2500 kg
- Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
- Calibration of force-measuring devices
- DAKkS calibration certificates in the following languages DE, GB, FR, IT, ES, NL, PL
- Conformity evaluation and reverification of balances and test weights

Your KERN specialist dealer: