





Radio platform scales with touchless tare function

Features

- · Display device with integrated radio module for wireless communication with the weighing platform: ideal for weighing contaminated items, weighing in loud environments or with physical separation. Range approx. 10 m
- II Touchless tare function: by the wave of your hand. No need to operate the scale with dirty gloves anymore
- Network operation: 3 frequencies for parallel use of several weighing platforms with a single display device
- · High mobility thanks to battery operation for display device and platform
- · Simple and convenient 5-key operation
- · Wall mount for display device, standard
- · Hold function: When the weighing conditions are unstable, a stable weight is calculated determining an average value

Technical data

- Large LCD display, digit height 25 mm
- · Weighing plate dimensions, stainless steel W×D×H
 - 315×305×55 mm
 - **B** 550×550×65 mm
 - © 900×550×60 mm
- Dimensions of display device W×D×H 215×110×45 mm
- Optional battery operation, 6×1.5 V AA not included, operating time up to 60 h
- · Permissible ambient temperature 10 °C/35 °C

Accessories

- Protective working cover, can be re-ordered, scope of delivery: 5 items, KERN EOB-A02S05
- Stand to elevate display device, can be retrofitted, for models with weighing plate size A, height of stand approx. 450 mm, KERN EOB-A01N
- · Stand to elevate display device, height of stand approx. 950 mm, can be retrofitted, KERN MWS-A01
- KERN EOS-F: Non-slip rubber mat, W×D×H 900×550×5 mm. Can be re-ordered, KERN EOS-A01

STANDARD

























Model	Weighing range	Readout	Reproducibility	Linearity	Weighing plate	Options	
						DAkkS Calibr. Certificate	
	[Max]	[d]				DKD	
KERN	kg	g	g	g		KERN	
EOB 35K-2F	35	10	10	± 20	А	963-128	
EOB 60K-2F	60	20	20	± 40	А	963-129	
EOB 60K-2LF	60	20	20	± 40	В	963-129	
EOB 150K-2F	150	50	50	± 100	А	963-129	
EOB 150K-2LF	150	50	50	± 100	В	963-129	
EOB 300K-1LF	300	100	100	± 200	В	963-129	
EOS 150K50XLF	150	50	50	± 100	C	963-129	
EOS 300K100XLF	300	100	100	± 200	C	963-129	

KERN Pictograms:



Internal adjusting: Quick setting up of the balance's accuracy with internal adjusting weight (motordriven).



Piece counting: Reference quantities selectable. Display can be switched from piece to weight.



Rechargeable battery pack:

C) EU, GB, CH, USA, AUS

Rechargeable set.



Adjusting program CAL: For quick setting up of the balance's accuracy. External adjusting weight required.



Recipe level A: Separate memory for the weight of the tare container and the recipe RECIPE ingredients (net total).



Universal mains adapter: with universal input and optional input socket adapters for

MULTI

A) EU, GB B) EU, GB, CH, USA



Memory: Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



Recipe level B: Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display.



Mains adapter: 230V/50Hz in standard version for EU. On request GB, USA or AUS version available.



Alibi memory: Electronic archiving of weighing results, complying with the 2014/31/EU standard.



Recipe level C: Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display, multiplier function, adjustment of recipe when dosages are exceeded or barcode recognition.



Power supply: Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request.



Data interface RS-232: To connect the balance to a printer, PC or network.



Totalising level A: The weights of similar items can be added together and the total



Weighing principle: Strain gauge Electrical resistor on an elastic deforming body.



RS-485 data interface: To connect the balance to a printer, PC or other peripherals. High tolerance against electromagnetic disturbance.



can be printed out.



Weighing principle: Tuning fork A resonating body is electromagnetically excited, causing it to oscillate.



USB data interface: To connect the balance to a printer, PC or other peripherals.



Percentage determination: Determining the deviation in % from the target value



Weighing principle: Electromagnetic force compensation Coil inside a permanent magnet. For the most accurate weighings.



Bluetooth* data interface: To transfer data from the balance to a printer, PC or other peripherals.



Weighing units: Can be switched to e.g. nonmetric units at the touch of a key. See balance model. Please refer to KERN's website for more details.



Weighing principle: Single cell technology Advanced version of the force compensation principle with the highest level of precision.



WLAN data interface: To transfer data from the balance to a printer, PC or other peripherals.



Weighing with tolerance range: Upper and lower limiting values can be programmed individually for e.g. dosing, sorting and portioning.



Verification possible:

The time required for verification is specified in the pictogram.



Control outputs (optocoupler, digital I/O): To connect relays, signal lamps, valves, etc.



Hold function: (Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average



DAkkS calibration possible (DKD): The time required for DAkkS calibration is shown in days in the pictogram.



Interface for second balance: For direct connection of a second balance.



Protection against dust and water splashes IPxx: The type of protection is shown in the pictogram.



Package shipment: The time required for internal shipping preparations is shown in days in the pictogram.



Network interface: For connecting the scale to an Ethernet network. With KERN products you can use a universal RS-232/LAN converter.



ATEX explosion protection: Suitable for use in hazardous industrial environments, in which there is explosion danger. The ATEX marking is specified for each device.



Pallet shipment: The time required for internal shipping preparations is shown in days in the pictogram.



Wireless data transfer: between the weighing unit and the evaluation unit using an integrated radio module.



Stainless steel: The balance is protected against corrosion.



Warranty: The warranty period is shown in the pictogram.



GLP/ISO log: The balance displays the weight, date and time, regardless of a printer connection.



Suspended weighing: Load support with hook on the underside of the balance.



GLP/ISO log: With weight, date and time. Only with KERN printers.



Battery operation: Ready for battery operation. The battery type is specified for each device.

KERN – Precision is our business

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAkkS calibration certificate the best pre-requisite for proper balance calibration.

The KERN DAkkS calibration laboratory today is one of the most modern and best-equipped DAkkS calibration laboratories for balances, test weights and forcemeasurement in Europe.

Thanks to the high level of automation, we can carry out DAkkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

Range of services:

- DAkkS calibration of balances with a maximum load of up to 50 t
- DAkkS calibration of weights in the range of 1 mg 2500 kg
- · Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
- Calibration of force-measuring devices
- DAkkS calibration certificates in the following languages DE, GB, FR, IT, ES, NL, PL
- · Conformity evaluation and reverification of balances and test weights

Your KERN specialist dealer:

*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owner