

IoT-Line Bench Scale KERN FKB









High resolution bench scale with large weighing range and robust stainless steel weighing plate

Features

- Thanks to the high resolution of up to 360.000 points it is ideal for high-precision weighing in the industrial field
- Robust plastic die-cast housing: maintains the stability, protects the weighing technology elements and is robust enough to cope with everyday use
- Industry 4.0: The integrated KERN Universal Port (KUP) allows the connection of external KUP interface adapters such as RS-232, USB, Bluetooth, WiFi, Analogue, Ethernet etc. The outstanding advantage here is that the KUP interface adapters are simply plugged in, i.e. retrofitting interfaces is conveniently possible without opening the scale housing or complicated installation. The interface adapters enable convenient transmission of weighing data to networks, PCs, smartphones,

tablets, laptops, printers etc. In addition, control commands and data inputs can also be sent to the scale via the connected devices.

Tip: with the KERN KUP-13 extension box, up to three KUP interface adapters can be operated in parallel on the scale

- KERN Communication Protocol (KCP): The KCP permits searching and remote control of the balance using external control devices or computers
- PRE-TARE function for manual subtraction of a known container weight, useful for checking fill-levels
- Freely programmable weighing unit, e.g. display direct in special units such as length of wire g/m, surface weight g/m², or else
- Level indicator and levelling feet for precise levelling of the scale, fitted as standard
- Protective working cover included with delivery

KERN

IoT-Line Bench Scale KERN FKB







Technical data

- Large backlit LCD display, digit height 25 mm
- Dimensions weighing surface, stainless steel, W×D $340\times240~\text{mm}$
- Overall dimensions W×D×H, 350×390×120 mm
- Optional battery operation, 4×1.5 V AA not included in scope of delivery, operating time up to 20 h
- Net weight approx. 7 kg
- Permissible ambient temperature -10 $^{\circ}\text{C}/40~^{\circ}\text{C}$

Accessories

- Protective working cover, scope of delivery 5 items, KERN FKB-A02S05
- Internal rechargeable battery pack, operating time up to 48 h without backlight, charging time approx. 8 h, KERN YKR-01
- External data interface USB, interface cable included, KERN KUP-03
- External data interface RS-232, interface cable included, KERN KUP-01
- Interface adapter Ethernet, KERN KUP-04
- Interface adapter WiFi, KERN KUP-05
- Bluetooth interface adapter, KERN KUP-06
- Extension box for connecting up to three interfaces in parallel, KERN KUP-13
- Tare pan made from stainless steel, ideal for weighing loose small parts as well as fruits, vegetables, etc., overall dimensions W×D×H 400×300×45 mm, KERN RFS-A02
- Further details, plenty of further accessories and suitable printers see *Accessories*

■ Particularly practical: thanks to the large weighing ranges and compact dimensions, you can accurately weigh heavy loads in the most restricted of spaces. Useful for determining very small weight differences, such as, for example, gas wastage, abrasion of mechanical parts, rock samples, minerals, druses, silver etc.

STANDARD











































Model	Weighing capacity [Max]	Readability [d]	Reproducibility	Linearity	Smallest part weight (Normal)	Resolution	Options DAkkS Calibr. Certificate DAkkS
KERN	kg	g	g	g	g/piece	Points	KERN
FKB 6K0.02	6	0,02	0,04	± 0,1	0,2	300.000	963-128
FKB 8K0.05	8	0,05	0,05	± 0,15	0,5	160.000	963-128
FKB 16K0.05	16	0,05	0,1	± 0,25	0,5	320.000	963-128
FKB 8K0.1	8	0,1	0,1	± 0,3	1	80.000	963-128
FKB 16K0.1	16	0,1	0,1	± 0,3	1	160.000	963-128
FKB 15K0.5	15	0,5	0,5	± 1,5	10	30.000	963-128
FKB 36K0.1	36	0,1	0,2	± 0,5	1	360.000	963-128
FKB 36K0.2	36	0,2	0,4	± 1	2	180.000	963-128
FKB 65K0.2	65	0,2	0,4	± 1	2	325.000	963-129
FKB 30K1	30	1	1	± 3	20	30.000	963-128
FKB 65K1	65	1	1	± 3	20	65.000	963-129

BALANCES & TEST SERVICE 2024

KERN Pictograms





Internal adjusting

Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)



Adjusting program CAL

For quick setting up of the balance's accuracy. External adjusting weight required



EasyTouch

Suitable for the connection, data transmission and control through PC or tablet



Memory

Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



Alibi memory

Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard.



KERN Universal Port (KUP)

allows the connection of external KUP interface adapters, e.g. RS-232, RS-485, SB, Bluetooth, WIFI, Analogue, Ethernet etc. for the exchange of data and control commands, without installation effort



RS-232 Data interface

To connect the balance to a printer, PC or network



RS-485 Data interface

To connect the balance to a printer, PC or other peripherals. Suitable for data transfer over large distances. Network in bus topology is possible



USB Data interface

To connect the balance to a printer, PC or other peripherals



Bluetooth* Data interface

To transfer data from the balance to a printer, PC or other peripherals



WIFI Data interface

To transfer data from the balance to a printer, PC or other peripherals



Control outputs

(optocoupler, digital I/O) To connect relays, signal lamps, valves, etc.



Analogue interface

to connect a suitable peripheral device for analogue processing of the measurements



Interface for second balance

For direct connection of a second balance



Network interface

For connecting the scale to an Ethernet network



KERN Communication Protocol (KCP)

It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems



GLP/ISO log intern

The balance displays weight, date and time, independent of a printer connection



GLP/ISO log Printer

With weight, date and time. Only with KERN printers.



Piece counting

Reference quantities selectable. Display can be switched from piece to weight



Recipe level A

The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out



Recipe level B

Internal memory for complete recipés with name and target value of the recipe ingredients. User guidance through display



Totalising level A

The weights of similar items can be added together and the total can be printed out



Percentage determination Determining the deviation in % from the target value (100 %)



Weighing units

Can be switched to e.g. nonmetric units. See balance model. Please refer to KERN's website for more details



Weighing with tolerance range (Checkweighing)

Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model



Hold function

(Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value



Protection against dust and water splashes IPxx

The type of protection is shown in the pictogram

Suspended weighing

Load support with hook



on the underside of the balance

Battery operation Ready for battery opera-

tion. The battery type is



BATT

specified for each device

Rechargeable battery pack Rechargeable set



Universal plug-in power supply

with universal input and optional input socket adapters for A) EU, CH, GB B) EU, CH, GB, US C) EU, CH, GB, US, AUS



230V/50Hz in standard version for EU, CH. On request GB, USA or AUS version available

Plug-in power supply



Integrated power supply unit

Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request



Weighing principle Strain gauges

Electrical resistor on an elastic deforming body



Weighing principle Tuning fork

A resonating body is electromagnetically excited, causing it to oscillate



Weighing principle Electromagnetic force compensation

Coil inside a permanent magnet. For the most accurate weighings



Weighing principle Single cell technology

Advanced version of the force compensation principle with the highest level of precision

M

Conformity Assessment

The time required for conformity assessment is specified in the pictogram



DAkkS calibration possible (DKD)

. The time required for DAkkS calibration is shown in days in the pictogram



Factory calibration (ISO)

The time required for Factory calibration is shown in days in the pictogram



Package shipment

The time required for internal shipping preparations is shown in days in the pictogram



Pallet shipment

The time required for internal shipping preparations is shown in days in the pictogram



^{*}The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners